

P 486A

POWER CONTROLLER (VARIAC)



FRONT PANEL: VOLT METER. Power on indicator / POWER switch: ON or OFF switch.
AMMETER. ⚡ INPUT indicator / switch / OUTPUT indicator. AMMETER RANGE: 2A fuse / switch / 20A fuse. ⚡ Voltage selector: 0, 10, 20, 30, 40, 50, 60, 70, 80, 90, 100, 110, 120, 130, 140. MAIN POWER 20A fuse.



P 486A - Sold from ???? - ???? S/N: ??1001~?????? (?,???? UNITS)

Size: ?"H, ?"W and ?"D. **Weight:** ? lb. **\$???.**