

“Shelf Bracket” introduced in 1963 for the **MA 230**. There is no Panloc button on front and no mechanism on rear. Side brackets just had a hole and the supplied 2 knurled headed screws to go through the bracket and into the **MA 230** (and later **MA 5100**) to secure it.

**EARLY PRODUCTION SHELF BRACKETS 043-235 (L) & 043-234 (R)**  
**FOR L 11 CABINET AND –**

**INTEGRATED AMPLIFIER:**

**MA 230**



**MA 230**

"Full" Panloc introduced in 1963.



**EARLY FULL PAN FOR C 22 AND –  
L 11 CABINET**



**FRONT**



**REAR**



**MX 110**

Subsequent Panlocs had individual right and left brackets. Panloc could be used for **McIntosh** equipment cabinets or for custom panel mounting.





**TYPICAL PANLOC BRACKETS AND CABINET MOUNTING HARDWARE**



**CUSTOM PANEL MOUNTING HARDWARE 044-890**



**CUSTOM PANEL MOUNTING TEMPLATE 038-179**







**EARLY PRODUCTION PANLOC BRACKETS 043-593 (L) & 043-592 (R) FOR L 12 CABINET AND –**

**PRE-AMPS:**

**C 22  
C 24**

**TUNER/PRE-AMP:**

**MX 110 (LATE)**

**TUNERS:**

**MR 67  
MR 71**



**FRONT**



**REAR**



**MR 67**



**MX 110**



**EARLY PRODUCTION PANLOC BRACKETS 043-428 (L) & 043-427 (R)  
FOR L 12 CABINET AND -**

**SCOPE:**

**MI 3**



**MI 3**



**MID-PRODUCTION PANLOC BRACKETS 043-679 (L) & 043-678 (R)  
FOR L 14, L 54 & L 54A CABINET AND -**

**POWER AMPS:**

- MC 2105**
- MC 2205**
- MC 2255**
- MC 2002**



**FRONT**



**REAR**



**MC 2105**



**MC 2255**



**MID-PRODUCTION PANLOC BRACKETS 044-209 (L) & 044-210 (R)**  
**FOR 030-011 CABINET AND -**  
**EQUALIZER:**  
**MQ 101**



**FRONT**



**REAR**



**MQ 101**





**LATE PRODUCTION PANLOC BRACKETS 003-509 (L) & 005-508 (R) AND 042-593 (L) & 043-592 (R) [MC 2125, MC 2155 & MA 6200] FOR L 52 & L52A CABINET AND -**

**POWER AMPS:**

MC 2125  
MC 2155

**PRE-AMPS:**

C 27, C 32, C 29,  
C 33, C 30, C 34V,  
C 31V, C 35, C 37,  
C 36

**TUNERS:**

MR 75  
MR 80

**DISC PLAYERS:**

MCD 7000  
MCD 7005  
MCD 7007

**INTEGRATED AMP:  
MA 6200**

**TUNER/PRE-AMP:  
MX 117**



**FRONT**



**REAR**



**MC 2125**



**MX 117**





LATE PRODUCTION PANLOC BRACKETS **045-901** (L) & **045-902** (R)  
FOR **L 50** CABINET AND -

**POWER AMP:**

**MC 502**

**PRE-AMP:**

**C 504**

**TUNERS:**

**MR 500**

**MR 510**



**FRONT**



**REAR**



**C 504**



**MR 500**



**LATE-PRODUCTION PANLOC BRACKETS 003-509 (L) & 003-508 (R)  
AND 046-575 (L) & 046-574 (R) [MCD 7000]  
FOR L 52A CABINET AND -**

***PRE-AMP:***  
**C31 V**

***DISC PLAYERS:***  
**MCD 7000**  
**MCD 7005**  
**MCD 7007**



**FRONT**




**REAR**



**MCD 7000**



**MCD 7007**



LATE-PRODUCTION PANLOC BRACKETS **003-760** (L) & **003-761** (R)  
FOR L 54 & L 54 W CABINET AND -

**POWER AMPS:**

- MC 7200**
- MC 7270**
- MC 7300**



**FRONT**



**REAR**



**MC 7200**




**MC 7270**

The Panloc system was discontinued in 1992.



Remove the plastic shipping feet from the bottom of the instrument (if attached):




Guide the AC power cord through the panel opening to the back of the cabinet. Then slide the instrument into the opening carefully so that the rails on the bottom of each side of the instrument chassis engage the tracks on the **PANLOC** mounting brackets:



Continue to slide the instrument into the cabinet until it is stopped by the “**adjust**” **position latches** on the side of the instrument. This “**adjust**” **position** allows access to the top controls on many instruments:



Press the instrument "adjust" position latches on each side inward:



This permits the instrument to slide further into the cabinet until its front panel is flush with the cabinet panel.

Depress the **PANLOC** buttons at the lower left and right corners of the instrument panel to **lock** the unit firmly in the cabinet:



The "cup" on the rear end of the **PANLOC** rods must engage the receptacle on the rear of each **PANLOC** bracket for the **PANLOC** buttons to lock the instrument in place:



Depressing the **PANLOC** buttons again will **unlock** the instrument so that it can be slid forward to the "adjust" position. Pressing inward on the "**adjust**" **position latches** permits removal of the instrument from the cabinet.